

Devices supported:

PIC16F Devices:

- PIC16F722, 723, 724, 726, 727
 - PIC16F737, 747, 767, 777
 - PIC16F87, 88
 - PIC16F818, 819
 - PIC16F870, 871, 872, 873, 874, 876, 877
 - PIC16F873A, 874A, 876A, 877A
 - PIC16F882, 883, 884, 886, 887
 - PIC16F913, 914, 916, 917
 - PIC16F946
-

PIC18F Devices:

- PIC18F242, 252, 442, 452
 - PIC18F248, 258, 448, 458
 - PIC18F1220, 1320, 2220, 2320
 - PIC18F1230, 1330
 - PIC18F2221, 2321
 - PIC18F2331, 2410, 2420, 2431
 - PIC18F2423
 - PIC18F2450, 2455, 2458, 2480
 - PIC18F2510, 2515, 2520, 2523
 - PIC18F2525
 - PIC18F2550, 2553, 2580, 2585
 - PIC18F2610, 2620, 2680
 - PIC18F2682, 2685
 - PIC18F4220, 4221
 - PIC18F4320, 4321, 4331
 - PIC18F4410, 4420, 4423
 - PIC18F4431, 4450, 4455
 - PIC18F4458, 4480
 - PIC18F4510, 4515, 4520, 4523
 - PIC18F4525, 4550, 4553, 4580
 - PIC18F4585
 - PIC18F4610, 4620, 4680
 - PIC18F4682, 4685
 - PIC18F6310, 6390, 6393
 - PIC18F6410, 6490, 6493
 - PIC18F6520, 6525, 6527, 6585
 - PIC18F6620, 6621, 6622, 6627
 - PIC18F6628, 6680
 - PIC18F6720, 6722, 6723
 - PIC18F8310, 8390, 8393
 - PIC18F8410, 8490, 8493
 - PIC18F8520, 8525, 8527, 8585
 - PIC18F8621, 8620, 8622, 8627
 - PIC18F8628, 8680
 - PIC18F8720, 8722, 8723
-

-
- PIC18F24J10, 25J10, 44J10, 45J10
 - PIC18F24J11, 25J11, 26J11, 44J11, 45J11, 46J11
 - PIC18F24J50, 25J50, 26J50, 44J50, 45J50, 46J50
 - PIC18F63J11, 63J90, 64J11, 64J90
 - PIC18F65J10, 65J11, 65J15
 - PIC18F65J50, 65J90
 - PIC18F66J10, 66J11, 66J15, 66J16
 - PIC18F66J50, 66J55, 66J60, 66J65
 - PIC18F66J90
 - PIC18F67J10, 67J11, 67J50, 67J60
 - PIC18F67J90
 - PIC18F83J11, 83J90, 84J11, 84J90
 - PIC18F85J10, 85J11, 85J15, 85J50
 - PIC18F85J90
 - PIC18F86J10, 86J11, 86J15, 86J16
 - PIC18F86J50, 86J55, 86J60, 86J65
 - PIC18F86J90
 - PIC18F87J10, 87J11, 87J50, 87J60
 - PIC18F87J90
 - PIC18F96J60, 96J65
 - PIC18F97J60
 - PIC18F13K50*, 14K50*

PIC24 Devices:

- PIC24F08KA101, 08KA102
 - PIC24F16KA101, 16KA102
 - PIC24FJ16GA002, 16GA004
 - PIC24FJ32GA002, 32GA004
 - PIC24FJ48GA002, 48GA004
 - PIC24FJ64GA002, 64GA004
 - PIC24FJ64GA006, 64GA008, 64GA010
 - PIC24FJ64GB106, 64GB108, 64GB110
 - PIC24FJ96GA006, 96GA008, 96GA010
 - PIC24FJ128GA006, 128GA008, 128GA010
 - PIC24FJ128GA106, 128GA108, 128GA110
 - PIC24FJ128GB106, 128GB108, 128GB110
 - PIC24FJ192GA106, 192GA108, 192GA110
 - PIC24FJ192GB106, 192GB108, 192GB110
 - PIC24FJ256GA106, 256GA108, 256GA110
 - PIC24FJ256GB106, 256GB108, 256GB110
 - PIC24HJ12GP201, 12GP202
 - PIC24HJ16GP304
 - PIC24HJ32GP202, 32GP204
 - PIC24HJ32GP302, 32GP304
 - PIC24HJ64GP202, 64GP204
 - PIC24HJ64GP206, 64GP210, 64GP506
 - PIC24HJ64GP502, 64GP504, 64GP510
 - PIC24HJ128GP202, 128GP204
 - PIC24HJ128GP206, 128GP210, 128GP306
-

-
- PIC24HJ128GP310
 - PIC24HJ128GP502, 128GP504
 - PIC24HJ128GP506, 128GP510
 - PIC24HJ256GP206, 256GP210, 256GP610

dsPIC30 Devices:

- dsPIC30F1010
- dsPIC30F2010, 2011, 2012
- dsPIC30F2020, 2023
- dsPIC30F 3010, 3011, 3012
- dsPIC30F3013, 3014
- dsPIC30F4011, 4012, 4013
- dsPIC30F5011, 5013, 5015, 5016
- dsPIC30F6010A, 6011A, 6012A
- dsPIC39F6013A, 6014A, 6015

dsPIC33 Devices:

- dsPIC33FJ12GP201, 12GP202
 - dsPIC33FJ16GP304
 - dsPIC33FJ32GP202, 32GP204
 - dsPIC33FJ32GP302, 32GP304
 - dsPIC33FJ64GP202, 64GP204
 - dsPIC33FJ64GP206, 64GP306, 64GP310
 - dsPIC33FJ64GP706, 64GP708, 64GP710
 - dsPIC33FJ64GP802, 64GP804
 - dsPIC33FJ128GP202, 128GP204
 - dsPIC33FJ128GP206, 128GP306, 128GP310
 - dsPIC33FJ128GP706, 128GP708, 128GP710
 - dsPIC33FJ128GP802, 128GP804
 - dsPIC33FJ256GP506, 256GP510, 256GP710
 - dsPIC33FJ06GS101, 06GS102, 06GS202
 - dsPIC33FJ16GS402, 16GS404
 - dsPIC33FJ16GS502, 16GS504
 - dsPIC33FJ12MC201, 12MC202
 - dsPIC33FJ16MC304
 - dsPIC33FJ32MC202, 32MC204
 - dsPIC33FJ32MC302, 32MC304
 - dsPIC33FJ64MC202, 64MC204
 - dsPIC33FJ64MC506, 64MC508, 64MC510
 - dsPIC33FJ64MC706, 64MC710
 - dsPIC33FJ64MC802, 64MC804
 - dsPIC33FJ128MC202, 128MC204
 - dsPIC33FJ128MC506, 128MC510
 - dsPIC33FJ128MC706, 128MC708, 128MC710
 - dsPIC33FJ128MC802, 128MC804
 - dsPIC33FJ256MC510, 256MC710
-